



NEW: POLISHING SET FOR WOODEN PARTS



Polishing agent and polishing cloth



A dirty area on the harp



Apply polishing agent to affected area and remove stain. Wait briefly and polish again.



Polished area after second application

Do not use polishing agent on metal parts or gilded areas to avoid possible discolorations.

Konzertharfenbau Horngacher GmbH
Söckinger Strasse 23 - D-82319 Starnberg
Tel.: +49-8151-12920 Fax: -21204
E-Mail: info@horngacher-harps.de

Klaus Horngacher



Deutsche Bank Starnberg
Konto 5 950 506 (BLZ 700 700 24)
HypoVereinsbank Starnberg
Konto 6 320 291 990 (BLZ 700 202 70)

Registergericht München HRB 99196